

14 Channels Mode:

14 Channels						
Ch1	Ch2	Ch3	Ch4	Ch5	Ch6	Ch7
Pan	Pan Fine	Tilt	Tilt Fine	P/T Speed	Reset	Dimmer
255 540°  0 0°	255  0	255 220°  0 0°	255  0	255 Slow  0 Fast	015-255 No function  010-014 Reset all  000-009 No function	255 100%  0 0%
Ch8		Ch9	Ch10	Ch11	Ch12	
Shutter		Beam Red	Beam Green	Beam Blue	Beam White	
245-255 open 230-244 burst 225-229 open 210-224 sine wave 205-209 open 190-204 random burst pulse 185-189 open 170-184 burst pulse 165-169 open 150-164 random closing pulse 145-149 open 130-144 random opening pulse 125-129 open 110-124 random strobe 105-109 open 090-104 closing pulse 085-089 open 070-084 opening pulse 065-069 open 025-064 strobe 020-024 open 000-019 closed		255 100%  0 0%	255 100%  0 0%	255 100%  0 0%	255 100%  0 0%	

Color wheel effect			
000-009	Open		
010-014	LEE 790 - Moroccan pink		
015-019	LEE 157 - pink		
020-024	LEE 332 - Special rose pink		
025-029	LEE 328 - Follies pink		
030-034	LEE 345 - Fuchsia pink		
035-039	LEE 194 - Surprise pink		
040-044	LEE 181 - Congo blue		
045-049	LEE 071 - Tokyo blue		
050-054	LEE 120 - Deep blue		
055-059	LEE 079 - Just blue		
060-064	LEE 132 - Medium blue		
065-069	LEE 200 - Double CT blue		
070-074	LEE 161 - State blue		
075-079	LEE 201 - Full CT blue		
080-084	LEE 202 - Half CT blue		
085-089	LEE 117 - Steel blue		
090-094	LEE 353 - Lighter blue		
095-099	LEE 118 - Light blue		
100-104	LEE 116 - Medium blue green		
105-109	LEE 124 - Dark green		
110-114	LEE 139 - Primary green		
115-119	LEE 089 - Moss green		
120-124	LEE 122 - Fern green		
125-129	LEE 738 - JAS green		
130-134	LEE 088 - Lime green		
135-139	LEE 100 - Spring yellow		
140-144	LEE 104 - Deep amber		
145-149	LEE 179 - Chrome orange		
150-154	LEE 105 - Orange		
155-159	LEE 021 - Gold amber		
160-164	LEE 778 - Millennium gold		
165-169	LEE 135 - Deep gold amber		
170-174	LEE 164 - Flame red		
175-179	Open		
Ch 13	Color wheel rotation effect		
	180-201	Clockwise, fast to slow	
	202-207	Stop(this will stop wherever the color is at the time)	
	208-229	Counter-clockwise, slow to fast	
	230-234	Open	
	Ch 14	Random color	
		235-239	Fast
		240-244	Medium
		245-249	Slow
		250-255	Open
	Zoom		
	000-255		